


# ASPHALT PLANT SPARES



## WEAR PART CASTINGS

Mixer, Dryer, Elevator, Burner,  
Chains, Shafts, Paddle arms etc.

## SPARES

Shafts, Screen tubes, Bearings,  
Bearing housings, Labyrinths,  
Springs etc.



## SERVICE

From major plant refurbishments to  
plant inspections we have fully trained  
engineers available.

**CALL**  
**01530 817000**



**FAX**  
**01530 817111**

*email : sales@crushers.co.uk*  
Crusher Manganese Steels Ltd

Vulcan Way, Hermitage Industrial Estate, Coalville, Leicestershire, LE67 3AP

**THE GENUINE ALTERNATIVE - SETTING THE STANDARD**